

TAKEMURA SB – CONFIGURATION

-
- 1) PC (laptop or desktop) Windows7/10

 - 2) Control software "TTW.EXE"

 - 3) Fiber optic adapter: interface for optical fiber cable
* Optional USB-serial converter: if no serial port on PC



-
- 4) Optical fiber cable :
connection between PC / Driver Box



-
- 5) Driver Box II



-
- 6) Jacquard position sensor:
photomicro sensors, and sensor cable




-
- 7) 50pin data cable(s):
connection between Driver Box / Connector Unit(s)



-
- 8) Connector Unit(s) : available for various types of jacquard
CON1344A for 1344 hooks, CON896A for 896 hooks, etc.,
(connectable)



-
- 9) Cassettes :
available for various types of jacquard



-
- 10) Frame Box :
available for various types of jacquard

